

CC-Dr. Schutz GmbH

Steinbrinksweg 30
D-31840
Hessisch Oldendorf
Fax: +49-(0)5152-9779-30
Tel: +49-(0) 5152-9779-0
info@dr-schutz.com
www.dr-schutz.com

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park
Smeaton close Aylesbury Bucks HP19 8UP
Great Britain
Fax: 01296-334 219
Tel: 01296-437 827
steve@dr-schutz.com
www.dr-schutz.com

Product-Information

Medica Hard Sealer



1. Product Description

A special floor sealer for the initial treatment of new or stripped floors. Its durable and long lasting protective film guards the floor against the penetration of disinfectants. For linoleum and vinyl flooring in hospitals and doctor's surgeries.

2. Areas of Application

Vinyl and linoleum floors. Use on rubber floors is possible only under certain circumstances and should be checked before use.

3. Method of Application

Shake Medica Hard Sealer well before use. Then apply an even, thin, undiluted coat lengthways to the surface of the cleaned floor (after installation or stripped), using the Polish Applicator System or the Quick Step System. When the protective film is firm to walk on (after approximately 1 hour), repeat the procedure in the crossways direction. Allow the film to dry for at least 12 hours before the floor is walked on, better still would be overnight.

Consumption: 1 l = 20 m² per coat.

Notes: Ensure that there is sufficient ventilation but avoid exposure to drafts and strong sunlight during application and drying processes and protect the surface from dust. Turn off under-floor central heating in good time prior to use.

Due to their ingredients, some disinfectant cleaners may dissolve or yellow the protective film. Therefore we recommend to use Dr. Schutz Disinfectant Cleaner. Ask our advisory services before using other concentrated disinfectant cleaners.

4. Technical Data

pH-level: 9.0 (concentrate)

Product code for cleaning and care products (Giscode): GE 10

Data on ingredients (EC recommendation): contains preservatives, perfumes, solvents, care-components.

Medica Hard Sealer should be stored in a cool, dry place in its closed original container. Keep locked up and out of the reach of children. Protect from frost.

5. Quality Inspection

Otto-Graf-Institute for material testing, University of Stuttgart, Germany, section 46 sport floors.

6. Unit Sizes

5 l canister

Art.-No. 2950000501

www.dr-schutz.com

The above advice on procedure for use is based on the best of our knowledge and the latest information available on cleaning technology. For this reason, when using our quality products, no damage will be incurred to the materials to be cleaned if strict attention is paid to the instructions printed on the container and the procedure suggested by us is followed. The use to which our products are put is, however, beyond our control. It is the responsibility of the user and does not release the user from making his own checks of the products supplied by us as to their suitability for the intended procedure and purposes. The information supplied by us is therefore non-binding and cannot be used as a basis for establishing the company's liability for any damage incurred. This also includes the infringement of any rights for the protection of third parties.