



eukula[®]
WOOD.FLOOR.LOVE

eukula care

1. PRODUCT DESCRIPTION

Dispersion care. Special water-based polymer coating. For the care and refreshing of thoroughly cleaned or thoroughly cleaned non-absorbent floors. Especially for: Lacquered wooden floors . For residential and commercial applications.

- Protects the floor.
- Reduces dirt adhesion and the time needed for day-to-day maintenance.
- Facilitates routine cleaning.
- Avoid excessive application of care products that darken due to prolonged use.

Available variants:

- Silk gloss, for glossy and semi matt floors.
- Matt, for matt floors.

Please take note of our specific floor care guides under www.dr-schutz.com.

2. APPLICATION

Thoroughly clean the floor before application. We recommend using a green pad and eukula clean .

Shake up well. Apply undiluted with the Dr. Schutz Polish Applicator or the Dr. Schutz Professional Mop at a minimum of 15 °C in an even, thin film to the surface in the direction of installation, after it has been thoroughly or thoroughly cleaned and dried. For increased protection, repeat the application when the care film is resistant to foot traffic.

Please note:

- Avoid strong sunlight and draughts during application.
- Switch off under-floor heating well in advance.
- Avoid excessive application of care products that darken due to prolonged use. An occasional stripping removes all care components, worn care films and possible accumulations of impurities from the surface. We recommend for this: eukula intensive cleaner , eukula professional remover . After stripping, a floor must be re-treated.



eukula[®]
WOOD.FLOOR.LOVE

eukula care

3. CONSUMPTION

25-30 g/m² per application (coverage: 30-40 m²/l)

4. DRYING TIME

Can be carefully walked on, or worked on again after the water has evaporated (30-60 minutes)
. Can be used with caution 12 hours after the last layer has dried.

5. STORAGE

Protect from frost. Store in a cool dry place. Keep out of the reach of children.

6. TECHNICAL DATA

Ingredients: water / polyacrylate / polyurethane / glycol ether / silicic acids / waxes / additives / perfumes TETRAMETHYL ACETYLOCTAHYDRONAPHTHALENES / preservation agents BRONOPOL BENZISOTHIAZOLINONE METHYLCHLOROISOTHIAZOLINONE METHYLISOTHIAZOLINONE / Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2-methyl-2H-isothiazol-3-one (3:1). May produce an allergic reaction.

GISCODE GE10 (Emulsions/Dispersions) (Germany)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: no labelling obligation. UFI: UUE0-N0VX-U00P-AUWH

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

7. SPECIAL NOTES

- All indications based on 23°C/50% rH/ 3-fold change of air per hour. Existing conditions can vary and account for different results.
- Please pay attention to the printed batch number. Only use products with the same batch number in one layer. In the case of different batches, mix these in a separate container before using.



eukula[®]
WOOD.FLOOR.LOVE

eukula care

- Before application on factory UV lacquers/PU finishes, the surface must be thoroughly pre-cleaned with Clean & Strip and green pad. Pre-testing for wetting and adhesion of the care film is recommended.
- Please note: It is not possible to make glossy surfaces satisfactorily matt with a matt care product. For this purpose, we recommend the application of a permanent lacquer with our PU lacquers.
- The application of care products on surfaces with an anti-slip effect must generally be looked at separately. We recommend a two-step procedure with pre-cleaning and subsequent application of the product as a wipe-on care in dilution 1:100. The frequency of application should be increased. Preferably, however, we recommend occasional recoating with a lacquer set to R-class in terms of maintenance.

8. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz surface products.
- Safety Data Sheet available on request.

www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.



eukula[®]
WOOD.FLOOR.LOVE

eukula care

eukula – contact us

Germany
Headquarter (international)

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

phone +49 (228) 95352-40
fax +49 (228) 95352-46
email: export@dr-schutz.com
www.dr-schutz.com

United Kingdom

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP
United Kingdom

contact: Richard Nelson
phone +44 (1296) 437827
fax +44 (1296) 334219
email: richard@drschutz.co.uk

Ireland

Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork
T12 R9F9
Republic of Ireland

contact: Paul O'Reardon
mobile +353 87 767 8388
email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.