



eukula[®]
WOOD.FLOOR.LOVE

eukula clean

1. PRODUCT DESCRIPTION

Neutral cleaning concentrate. For routine cleaning of wood and cork floors. For residential and commercial applications.

- Based on highly effective surfactants.
- Gentle removal of heavy soiling and grease.
- Excellent cleaning and emulsifying properties.
- Without dissolving care films.
- Without deposits on the surface and maintenance effect.
- Suitable for cleaning sports floors.

For cleaning after installation prior to applying care layers. Carefully coordinated cleaning and care system with eukula care . Please observe eukula care instructions for for wood and cork floors.

2. APPLICATION

Remove coarse dirt by sweeping or vacuuming.

For routine cleaning, dilute 1:200 (50 ml per 10 l) with water and wipe the floor with this cleaning solution until damp. Allow to dry.

Please note:

- Wood can swell when exposed to excessive water. Exposure to water through joints can lead to spotting. Therefore, always wipe only "damp" (with wrung-out cloths), do not leave puddles on the floor and keep water exposure short.
- Does not remove polymer coatings. For this we recommend: eukula intensive cleaner / eukula professional remover .
- For final cleaning, dilute in a ratio of 1:10 (1 litre to 10 litres of water). Work in sections to keep the exposure to water short. Apply cleaning solution with the mop and immediately emulsify dirt, waxes and surface silicones with the mono-disc machine/red pad. Take up the dirt water. Wipe damp with clean water.
- Regularly maintained wooden floors can be cleaned mechanically using the spray-suction method. To do this, dilute the product 1:400 (25 ml to 10 l water).



eukula[®]
WOOD.FLOOR.LOVE

eukula clean

3. CONSUMPTION

Routine cleaning: 0.1 litre per 100 m²

Final cleaning: 1 litre per 50 m²

4. STORAGE

Protect from frost. Store in a cool dry place. Keep out of the reach of children.

5. TECHNICAL DATA

Ingredients: water / less than 5% non-ionic surfactants , anionic surfactants / perfumes LIMONENE CITRONELLAL / preservation agents (BRONOPOL METHYLCHLOROISOTHIAZOLINONE METHYLISOTHIAZOLINONE)

GISCODE GU70 (daily cleaner, solvent-free, irritating) (Germany)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: GHS07, Warning. Causes serious eye irritation If medical advice is needed, have product container or label at hand. Keep out of reach of children. Wash ... thoroughly after handling. Wear eye protection/face protection. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention. Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2-methyl-2H-isothiazol-3-one (3:1). May produce an allergic reaction. UFI: WDD0-2056-N009-320E

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

6. SPECIAL NOTES

- Floors not only need to be cleaned, they also need to be maintained to protect and preserve their value and attractive appearance.
- Oiled-impregnated floors are leached out by water based cleaning. They must be re-impregnated with oils for maintenance. For this we recommend: eukula refresher Classic .



eukula[®]
WOOD.FLOOR.LOVE

eukula clean

7. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz surface products.
- Safety Data Sheet available on request.

www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.



eukula[®]
WOOD.FLOOR.LOVE

eukula clean

eukula – contact us

Germany
Headquarter (international)

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

phone +49 (228) 95352-40
fax +49 (228) 95352-46
email: export@dr-schutz.com
www.dr-schutz.com

United Kingdom

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP
United Kingdom

contact: Richard Nelson
phone +44 (1296) 437827
fax +44 (1296) 334219
email: richard@drschutz.co.uk

Ireland

Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork
T12 R9F9
Republic of Ireland

contact: Paul O'Reardon
mobile +353 87 767 8388
email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability – which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.