



eukula[®]
WOOD.FLOOR.LOVE

eukula professional remover

1. PRODUCT DESCRIPTION

Gentle strip cleaner with strong dissolving power and low alkalinity preventive to sensitive materials. Universal strip cleaner for all floorings. Especially for: Lacquered wooden floors / Floors sealed with a lacquer.

- Low odor.
- Labeling-free.
- Without addition of NTA or phosphate.
- pH 9,5-10

2. APPLICATION

Before use, test substrate for material suitability and colourfastness in an inconspicuous area. Mask off adjacent surfaces cleanly and protect from wetting.

Application concentration: For strip cleaning undiluted up to 1:5 diluted, depending on the maintenance film resistance. Apply cleaning solution liberally with a mop. A soak in time of 10 minutes is recommended. Thoroughly and slowly work the floor surface with a scrubbing brush, pad master or single-disc machine and a suitable pad or grit brush. Recommendation: green. Do not allow the cleaning liquor to dry on the floor during the cleaning process, therefore work in sections. Take up the dirty liquor and repeat the process if necessary. Rework with clear water and pad master or a single-disc machine until completely neutralised. Vacuum neutralisation liquor and allow to dry thoroughly.

For strip cleaning of lacquered wood floors, keep the amount of water and contact time low due to the risk of run-ins and spotting.

The cleaning result must be evaluated professionally. Dirt and care films must be removed. The maintenance or lacquering is carried out after complete drying.

Please note:

- Edge areas are best treated with the Dr. Schutz Pad Master.
- In order to remove the water, accelerate drying and reduce moistening the wood we recommend using the Dr. Schutz drying fan TGI.
- In general, please assess the water resistance of the entire floor when carrying out procedures with increased water use. For example, laying on chipboard can have unfavourable consequences if the floor covering is leaking during strip cleaning.
- Wear rubber gloves during application and ensure good ventilation of the rooms to be cleaned.



eukula[®]
WOOD.FLOOR.LOVE

eukula professional remover

3. CONSUMPTION

Strip cleaning: 10 m²/l undiluted up to 50 m²/l with a dilution 1:5 and a coverage of 100 ml/m².
Consumption may vary considerably depending on the situation.

4. STORAGE

Store in a cool dry place. Keep out of the reach of children.

5. TECHNICAL DATA

Ingredients: water / less than 5% non-ionic surfactants , anionic surfactants / perfumes LIMONENE
CITRAL / solvent

GISCODE GG20 (basic cleaner, unmarked, contains solvents). (German)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: no labelling obligation. UFI: SQ31-N0ME-800X-2TH6

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

6. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz surface products.
 - Safety Data Sheet available on request.
 - (*) Please pay attention to our Technical Information 002 „Preparation of subsurfaces“.
 - Follow project and flooring specific care instructions at www.dr-schutz.com.
- www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.



eukula[®]
WOOD.FLOOR.LOVE

eukula professional remover

eukula – contact us

Germany
Headquarter (international)

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

phone +49 (228) 95352-40
fax +49 (228) 95352-46
email: export@dr-schutz.com
www.dr-schutz.com

United Kingdom

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP
United Kingdom

contact: Richard Nelson
phone +44 (1296) 437827
fax +44 (1296) 334219
email: richard@drschutz.co.uk

Ireland

Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork
T12 R9F9
Republic of Ireland

contact: Paul O'Reardon
mobile +353 87 767 8388
email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical



eukula[®]
WOOD.FLOOR.LOVE

eukula professional remover

rules. On publication, this product information replaces and supersedes the validity of any previous versions.