

ESD Floor Cleaner

1. PRODUCT DESCRIPTION

Cleaning concentrate with strong wetting properties. For routine cleaning and final cleaning of hard floors. Especially recommended for conductive floors, also after lacquering with Dr. Schutz ESD lacquers.

- Streak-free cleaning.
- Excellent dirt binding, even with greasy residues.
- No leaching of the surface, no formation of grey haze.
- In application concentration pH-neutral.
- Suitable for use in automatic cleaning machines.

2. APPLICATION

Remove coarse dirt by sweeping or vacuuming.

For routine cleaning, dilute 1:200 (50 ml per 10 l) with water and wipe the floor with this cleaning solution until damp. Allow to dry. For use in automatic scrubbers/vacuum cleaners, the dilution can be increased to 1:400 (25 ml per 10 l).

For final cleaning, dilute in a ratio of 1:10 (1 litre to 10 litres of water). Spread the cleaning solution generously over the floor covering with a mop. Scrub after 10 minutes, for larger areas with a mono-disc machine / red pad. Absorb the dirt. Wipe off streak-free with clean water.

3. CONSUMPTION

Routine cleaning: 0.1 litre per 100 m²

4. STORAGE

Store in a cool dry place. Keep out of the reach of children.

5. TECHNICAL DATA

Ingredients: water / 5 % or over but less than 15 % non-ionic surfactants / less than 5% anionic surfactants / perfumes LIMONENE / preservation agents (BRONOPOL OCTYLISOTHIAZOLINONE GLUTARAL)

GISCODE GU40 (daily cleaner, solvent-free, unmarked)(Germany)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: no labelling obligation. UFI: 46G0-R0X9-R00M-WA7J

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

6. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

ESD Floor Cleaner

- General notes on the application of Dr. Schutz surface products.
- Safety Data Sheet available on request.
www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.

Dr. Schutz - We Care About Floors

Headquarter (international)
Germany

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

phone +49 (228) 95352-40
fax +49 (228) 95352-46
email: export@dr-schutz.com
www.dr-schutz.com

United Kingdom

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP
United Kingdom

contact: Richard Nelson
phone +44 (1296) 437827
fax +44 (1296) 334219
email: richard@drschutz.co.uk

Ireland

Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork
T12 R9F9
Republic of Ireland

contact: Paul O'Reardon
mobile +353 87 767 8388
email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.