

H2Oil

1. PRODUCT DESCRIPTION

Water-based care product. Maintenance oil for factory-oiled and hand-oiled wood and cork floors. Satin.

- Based on an oxidative curing oil emulsion.
- Protects the floor from abrasion and the wood from water.
- Gives old and dull floors a new look.
- Ready for use.
- Regular cleaning of the protected surface is simplified. We recommend for this purpose: Wood Care for oiled floors .

Available variants: Colorless / White (only recommended for surfaces that have been previously treated with a white oil)

Floor surfaces are subject to natural wear and tear depending on the amount of use. On absorptive substrates such as wood, regular maintenance is mandatory to maintain the value and prevent damage. If the surface has become damaged down to the wood through use, it must be sanded and recoated or oiled for restoration.

Please take note of our specific floor care guides under www.dr-schutz.com.

2. APPLICATION

In case of light soiling and for final cleaning, first clean the wood or cork floor with Dr. Schutz Wood Care for oiled floors in combination with a green pad. In the case of heavy soiling or running roads, clean first with Dr. Schutz Wood Floor Deep Clean diluted in water in a ratio of 1:1 to 1:3 and a green pad. After complete drying of the surface, apply the care product.

Shake up well. Apply undiluted with a dry Dr. Schutz Polish Applicator or a dry Dr. Schutz Professional Mop in an even, thin film in the direction of installation.

Please note:

- Avoid strong sunlight and draughts during application.
- Switch off under-floor heating well in advance.
- The temperature of the floor and material must not fall below +15°C during application and drying time. Ideal conditions are in the range of 18-25 °C.
- Clean the tools and working materials with water. Hardened product residues can only be removed mechanically.

3. CONSUMPTION

20-25 ml/m² (40 m²/l).

More product might be needed on rough or absorbent surfaces.

H2Oil

4. DRYING TIME

Carefully walk on after the water has evaporated (approx. 1 hour).

Carefully usable after approx. 12 hours.

Low temperatures, increased air humidity and poor ventilation can significantly extend the drying time.

5. STORAGE

Protect from frost. Store in a cool dry place. Keep out of the reach of children.

6. TECHNICAL DATA

Ingredients: water / modified vegetable oils / polyacrylate / silicic acids / waxes / additives / perfumes TETRAMETHYL ACETYLOCTAHYDRONAPHTHALENES / preservation agents (2-BROMO-2-NITROPROPANE-1,3-DIOL, METHYLCHLOROISOTHIAZOLINONE / METHYLISOTHIAZOLINONE, BENZISOTHIAZOLINONE) / Contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2-methyl-2H-isothiazol-3-one (3:1), 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction.

GISCODE GE10 (Emulsions/Dispersions) (Germany)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: no labelling obligation. UFI: 1111-Y073-S00M-J7F6 / 3411-F0WH-3003-7K18 White

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

7. SPECIAL NOTES

- All indications based on 23°C/50% rH/ 3-fold change of air per hour. Existing conditions can vary and account for different results.
- Leached and greyed wooden floors should be given a refresher impregnation before use. We recommend for this: Premium Care Oil

8. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz surface products.
- Safety Data Sheet available on request.

www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.

H2Oil

Dr. Schutz - We Care About Floors

Headquarter (international)
Germany

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

phone +49 (228) 95352-40
fax +49 (228) 95352-46
email: export@dr-schutz.com
www.dr-schutz.com

United Kingdom

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP
United Kingdom

contact: Richard Nelson
phone +44 (1296) 437827
fax +44 (1296) 334219
email: richard@drschutz.co.uk

Ireland

Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork
T12 R9F9
Republic of Ireland

contact: Paul O'Reardon
mobile +353 87 767 8388
email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.