



Medica Hard Sealer

1 PRODUCT DESCRIPTION

A special floor sealer for the initial treatment of new or stripped floors. Its durable and long lasting protective film guards the floor against the penetration of disinfectants. For linoleum and vinyl flooring in hospitals and doctor's surgeries. Dirt adhesion is reduced and day-to-day maintenance is made easier.

- Suitable for renovating care-film in a high-speed process.
- Creates a satin, antislip protective film ensuring a high degree of safety when walking on the treated surface.
- With increased resistance to disinfectants and compounds containing alcohol in comparison with conventional hard sealers (e.g. Dr. Schutz Secura Hard Sealer).

2 AREAS OF APPLICATION

Vinyl and linoleum floors. Use on rubber floors is possible only under certain circumstances and should be checked before use.

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

3 APPLICATION

Shake Medica Hard Sealer well before use. Then apply an even, thin, undiluted coat lengthways to the surface of the cleaned floor (after installation or stripped), using the Polish Applicator System or the Quick Step System. When the protective film is firm to walk on (after approximately 1 hour), repeat the procedure in the crossways direction. Allow the film to dry for at least 12 hours before the floor is walked on, better still would be overnight.

Notes: Ensure that there is sufficient ventilation but avoid exposure to drafts and strong sunlight during application and drying processes and protect the surface from dust. Turn off under-floor central heating in good time prior to use.

Due to their ingredients, some disinfectant cleaners may dissolve or yellow the protective film. Therefore we recommend to use Dr. Schutz Disinfectant Cleaner. Ask our advisory services before using other concentrated disinfectant cleaners.

4 CONSUMPTION

1 l = 20 m² per coat.

5 STORAGE

Medica Hard Sealer should be stored in a cool, dry place in its closed original container. Keep locked up and out of the reach of children. Protect from frost.



Medica Hard Sealer

6 TECHNICAL DATA

Data on ingredients (EC recommendation): contains preservatives, perfumes, solvents, care-components.

Product code for cleaning and care products (Giscode): GE 10

pH-level: 9.0 (concentrate)

ADR/RID: not a dangerous good as defined by transport regulations.

CLP: The product is not classified according to the CLP regulation. EUH208 Contains 1,2-benzisothiazol-3(2H)-one, reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7] and 2-methyl-2H-isothiazol-3-one [EC no. 220-239-6] (3:1). May produce an allergic reaction. EUH210 Safety data sheet available on request.

Even when using low-pollution products, the usual safety measures are to be observed. Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com.

Ensure that there is sufficient ventilation but avoid exposure to drafts and strong sunlight during application and drying processes and protect the surface from dust. Turn off under-floor central heating in good time prior to use. Due to their ingredients, some disinfectant cleaners may dissolve or yellow the protective film. Therefore we recommend to use Dr. Schutz Disinfectant Cleaner. Ask our advisory services before using other concentrated disinfectant cleaners.

8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.

Medica Hard Sealer



Dr. Schutz – We Care About Floors

Headquarter
Dr. Schutz GmbH
Holbeinstraße 17
D-53175 Bonn
Tel.: +49 (0)228 / 95 35 2-40
Fax: +49 (0)228 / 95 35 2-46
E-Mail: export@dr-schutz.com
www.dr-schutz.com

UK
Dr. Schutz U.K Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP

Contact: Richard Nelson
Tel.: +44 (0)1296 437827
Fax: +44 (0)1296 334219
E-Mail: richard@dr-schutz.com

Ireland
Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork

Contact: Paul O'Reardon
Mobile: 0877678388
E-Mail: drschutzireland@gmail.com

North America
Schutz NA
4701 Bath St 46
Philadelphia, PA 19137
USA

Contact: Sam Jamison
Tel.: +1(877) 272- 4889
Mobile: +1(215) 510- 7874
E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.