



PU Filler / Seamnomor

1 PRODUCT DESCRIPTION

Fast hardening 2-component polyester-filler.

- No shrinkage
- can be sanded very soon
- can be lacquered over with all Dr. Schutz 2K waterbased lacquers.
- Black
- only for use by professionals

2 AREAS OF APPLICATION

Filling holes and joints in floors which are solidly bound in the subsurface, generally before applying a colored design with Dr. Schutz PU Color.

Not recommended for soft floorings.

3 APPLICATION

Take out the required amount of **Dr. Schutz PU Filler** from the canister and put it onto a separate, non-absorbent flat surface. Squeeze the hardener (3%) from the enclosed hardener-tube next to the filler. Quickly mix the filler and hardener together with a Japanese spatula and fill any holes and hollows, which have been previously cleaned and abraded. After about 30 minutes the filling compound can and must be sanded down to the level of the surrounding floor. Sealing on top can be carried out immediately afterwards.

Please note:

- The surface must be professionally prepared and abraded as well as in a clean and dry condition, free of oil, wax and dust.
- Joints which are to be filled to improve the side adhesion should be cleanly cut on their sides
- Floor and material temperature must not fall below +15°C during application and drying time.
- Clean working tools and appliances mechanically after hardening.
- Read and follow work safety advice.
- When applied in areas including chair-rollers, we recommend fitting polycarbonate pads underneath after the renovation.

4 CONSUMPTION

Depends on the holes and hollows to be filled.

5 DRYING TIME

Can generally be worked on and sanded after 30 minutes.





PU Filler / Seamnomor

Low temperatures, high humidity and poor ventilation can prolong the drying time. Refrain from laying down carpets in the first 10-14 days. Furniture can be carefully placed. The area must not be wet mopped in the first three days.

7 STORAGE

Protect against frost. Store in a cool, dry place. Will keep for 24 months in unopened, original canister from the date of manufacture. Keep coating materials out of the reach of children.

8 TECHNICAL DATA

Contains: polyurethane resin, polyester resin, filler, styrene

ADR/RID: UN 3269 POLYESTER RESIN KIT, Klasse 3/III

CLP Basis GHS02, 07, 08 Danger. Contains Styrene. H226 Flammable liquid and vapour. H315 Causes skin irritation. H319 Causes serious eye irritation. H361d Suspected of damaging the unborn child. H372 Causes damage to the hearing organs through prolonged or repeated exposure.

CLP Hardener: GHS 02, 07, 09 Warning. Contains Dibenzoylperoxide. H242 Heating may cause a fire. H319 Causes serious eye irritation. H317 May cause an allergic skin reaction. H400 Very toxic to aquatic life.

9 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes

- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.





PU Filler / Seamnomor

Dr. Schutz – We Care About Floors

Headquarter	UK	Ireland		North America
CC-Dr. Schutz GmbH	Dr. Schutz U.K Ltd.	Dr. Schutz Ireland		Schutz NA
Holbeinstraße 17	Unit 24, Anglo Business Park,	35 Pic Du Jer Park,		4701 Bath St 46, Philadelphia
D-53175 Bonn	Smeaton Close, Aylesbury Bucks	Ballinlough, Cork		PA 19137, USA
Tel.: + 49 228 / 95 35 2-40	HP19 8UP			
Fax: + 49 228 / 95 35 2-46		Contact: Paul O'Reardon		Contact: Sam Jamison
E-Mail: export@dr-schutz.com	Contact: Richard Nelson	Mobile: 0877678388		Tel.: 001 / 877 272 4889
www.dr-schutz.com	Tel.: 0044 / 1296 437827	E-Mail:	drschutzire-	Mobile: 001 / 215 510 7874
	Fax: 0044 / 1296 334219	land@gmail.com		E-Mail: sam@schutzNA.com
	E-Mail: richard@dr-schutz.com			

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.

Brands of Dr. Schutz[•] GROUP Dr. Schutz[•] eu{ula[•] scratchnomore[•]