



# Lino Primer

## 1 PRODUCT DESCRIPTION

Two component roll-on primer for openpored linoleum. Only for professional users. Reduces porousness and prepares the subsurface for subsequent applications. Good penetrating quality, even visual impression, easy to use.

Optimal for subsequently applied Dr. Schutz PU sealers or Dr. Schutz hard sealers.

## 2 AREAS OF APPLICATION

Uncoated, openpored linoleum floorings, e.g. not factory-coated, after basic strip & clean, or after sanding.

Please pay attention to our technical recommendations specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com).

## 3 APPLICATION

Shake up **Lino Primer** well before adding the Crosslinker. Add **Crosslinker M** to the lacquer in a ratio of 20:1 and immediately mix thoroughly and evenly. After allowing it to settle for 10 minutes, stir again and then use. Do not mix more than can be used within 2 hours. Apply **Lino Primer** evenly with the Dr.Schutz Aquatop roller (minimum temp. 15°C) onto the subsurface which has been properly prepared for the application.

Please note:

- The surface must be professionally prepared and in a clean, dry condition free of oil, wax and dust (\*\*).
- Floor and material temperature must not fall below +15°C during application and drying time.
- The technical rules are to be observed.

## 4 CONSUMPTION

Per coating approx. 20-30 ml/m<sup>2</sup> (30-50 m<sup>2</sup>/l). In the case of a very absorbent sub-surface, higher consumption is possible, depending on absorbency.

## 5 DRYING TIME

Can be walked on carefully and worked on further with **Dr. Schutz PU Sealer** after approx. 1-2 hours, however not longer than 12 hours (at 20°C, 50% relative air humidity and sufficient ventilation).  
If working with Dr. Schutz Hard Sealers, keep to a drying time of at least 12 hours.

Low temperatures, high humidity and poor ventilation can prolong the drying time.

## 7 STORAGE

Protect against frost. Store in a cool, dry place. Will keep for 12 months in unopened, original canister from the date of manufacture. Keep coating materials out of the reach of children.

## Lino Primer



When stored in varying temperatures and/or in an opened canister, dried parts can form. If so, sieve these out before using.

### 8 TECHNICAL DATA

Contained substances: water, polyacrylate, polyurethane, glycoether, silicic acids, waxes, additives. Contains 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction.

voc (g/l) 37 in mixture (ISO11890) / GISCODE: W2DD+ / 2004/42/IIA(j)(140)140.

ADR/RID: not a dangerous good as defined by transport regulations (base lacquer and crosslinker).

CLP (base lacquer): labelling not necessary.

Emptied canisters can be disposed of in household waste, or taken to a recycling centre.

CLP (Crosslinker M): GHS 07, Attention. H332 Harmful if inhaled. H317 May cause an allergic skin reaction. H335 May cause respiratory irritation. H412 Harmful to aquatic life with long lasting effects. P280 Wear protective gloves / eye protection. P362 Take off contaminated clothing. P405 Store locked up. EUH204 Contains isocyanates. May produce an allergic reaction.

### 9 SPECIAL NOTES

- When mixed together, 2part-products can develop carbon dioxide and build up pressure. Never close 2part-mixtures tightly in a container, danger of bursting!
- Clean the working tools and implements with water. The hardened remains of lacquer can only be removed mechanically. We recommend always using new, dry Aquatop Rollers.
- Please pay attention to the printed batch number. Only use products with the same batch number in one layer. In the case of a different batch, mix this in a separate container before using.
- (\*) Please pay attention to our Technical Information „Preparation of subsurfaces“

### 10 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage [www.dr-schutz.com](http://www.dr-schutz.com) or on request from the address quoted below.

## Lino Primer



### Dr. Schutz – We Care About Floors

Headquarter  
CC-Dr. Schutz GmbH  
Holbeinstraße 17  
D-53175 Bonn  
Tel.: + 49 228 / 95 35 2-40  
Fax: + 49 228 / 95 35 2-46  
E-Mail: [export@dr-schutz.com](mailto:export@dr-schutz.com)  
[www.dr-schutz.com](http://www.dr-schutz.com)

UK  
Dr. Schutz U.K Ltd.  
Unit 24, Anglo Business Park,  
Smeaton Close, Aylesbury Bucks  
HP19 8UP

Contact: Richard Nelson  
Tel.: 0044 / 1296 437827  
Fax: 0044 / 1296 334219  
E-Mail: [richard@dr-schutz.com](mailto:richard@dr-schutz.com)

Ireland  
Dr. Schutz Ireland  
35 Pic Du Jer Park,  
Ballinlough, Cork

Contact: Paul O'Reardon  
Mobile: 0877678388  
E-Mail: [drschutzireland@gmail.com](mailto:drschutzireland@gmail.com)

North America  
Schutz NA  
4701 Bath St 46, Philadelphia  
PA 19137, USA

Contact: Sam Jamison  
Tel.: 001 / 877 272 4889  
Mobile: 001 / 215 510 7874  
E-Mail: [sam@schutzNA.com](mailto:sam@schutzNA.com)

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.