

CC-Dr. Schutz GmbH

Steinbrinksweg 30
D-31840
Hessisch Oldendorf
Fax: +49-(0)5152-9779-30
Tel: +49-(0) 5152-9779-0
info@dr-schutz.com
www.dr-schutz.com

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park
Smeaton close Aylesbury Bucks HP19 8UP
Great Britain
Fax: 01296-334 219
Tel: 01296-437 827
steve@dr-schutz.com
www.dr-schutz.com

Product-Information

Elatex Stain Remover

1. Product Description

A universal agent for the removal of rubber marks, heel marks, adhesive residue and stubborn stains.

2. Areas of Application

Resilient floors (vinyl, linoleum and rubber), laminates, sealed wood and cork floors, as well as carpets and upholstery.

3. Method of Application

A. Resilient floors, laminate, wood and cork floors:

For floors without a polish or sealer spray Elatex directly onto the soiled area. Leave to react for a short time, treat residues with a cloth or non-abrasive white pad. Finally wipe with clear water. Avoid long-lasting action on polymer-coated floors as well as sensitive surfaces (e.g. sealed wood and cork floors). In such cases spray Elatex onto a cloth and take up loosened stains carefully. Thereafter treat the floor with a suitable care agent.

B. Textile floors and upholstery:

Spray Elatex directly onto the stain and leave to draw for some minutes. Then loosen the stain by dabbing it with an absorbing cloth, working from the edges of the stain towards the centre. Remove loosened dirt by dabbing with a dry part of the cloth. Then treat with clear water and subsequently dab dry. If necessary, place the cloth on the treated area, weight it down somewhat and allow it to stand for a time until the liquid has been removed completely from the carpet.

Note: Do not inhale fumes. Before use, test the flooring with Elatex Stain Remover at an inconspicuous area for colourfastness, water resistance and material suitability. Reactions in the carpet fibres caused by the presence of stains may limit the effectiveness of Elatex Stain Remover.

4. Technical Data

pH level: 5.5 (concentrate)

Data on ingredients (EC recommendation): less than 5% anionic tensides. Contains preservatives. Other ingredients: care components, process materials and aromas.

Elatex Stain Remover should be stored in a cool, dry place in its closed original container. Protect from frost. Keep locked up and out of the reach of children.

Elatex Stain Remover

5. Unit Sizes

200 ml bottle with atomiser

Art.-No. 1320020016

www.dr-schutz.com

The above advice on procedure for use is based on the best of our knowledge and the latest information available on cleaning technology. For this reason, when using our quality products, no damage will be incurred to the materials to be cleaned if strict attention is paid to the instructions printed on the container and the procedure suggested by us is followed. The use to which our products are put is, however, beyond our control. It is the responsibility of the user and does not release the user from making his own checks of the products supplied by us as to their suitability for the intended procedure and purposes. The information supplied by us is therefore non-binding and cannot be used as a basis for establishing the company's liability for any damage incurred. This also includes the infringement of any rights for the protection of third parties.

