

CC-Dr. Schutz GmbH

Steinbrinksweg 30
D-31840
Hessisch Oldendorf
Fax: +49-(0)5152-9779-30
Tel: +49-(0) 5152-9779-0
info@dr-schutz.com
www.dr-schutz.com

Dr. Schutz UK Ltd.
Unit 24, Anglo Business Park
Smeaton close Aylesbury Bucks HP19 8UP
Great Britain
Fax: 01296-334 219
Tel: 01296-437 827
steve@dr-schutz.com
www.dr-schutz.com

Product-Information

Floor Mate

1. Product Description

Universal stain remover for synthetic fibre carpeting. Its active oxygen component is also effective in treating intensively coloured stains such as red wine, fruit tea, curry etc.

2. Areas of Application

Synthetic fibre rugs, carpets and fitted carpeting. Also suitable for use on resilient floor coverings, laminate flooring and water-resistant surfaces (e.g., tables, cupboards).

3. Method of Application

First dab up liquids using absorbent cloths. Take up loose dirt with the vacuum cleaner.

Spray Floor Mate onto a soft, absorbent, non-linting cloth (e.g., a suitable micro-fibre cloth) and loosen the stain using a dabbing action, working from the outer edges towards the centre. Do not rub. Take up any loosened dirt with a dry section of the cloth. In case of stubborn stains, repeat the process as necessary. Finally treat the area once again with clear water and then dab dry. When treating fitted carpeting, spread out and weight down a dry cloth if necessary to soak up any remaining fluid. Use a suitable care product for the final treatment of resilient floor coverings on which care products have already been used.

Spray a short burst of Floor Mate onto particularly stubborn stains (red wine, tea, etc.) following treatment and allow the stain remover to stand for a while before using water to perform final work on the stain.

Note: Before starting work, use Floor Mate at an inconspicuous place to check for colourfastness and material and paint / varnish suitability. Avoid allowing to stand for too long on sensitive surfaces (such as acrylic glass, varnished areas).

The effect of the product may be restricted if used to treat old stains that have become embedded in the flooring or respectively which cause a colour reaction.

Do not breath in fine spray and product vapours. During and after the use of larger quantities, ensure that the room is sufficiently well ventilated. Occasionally, in the case of prolonged or repeated contact, Floor Mate can give rise to a temporary whitish discoloration of sensitive or dry skin. For this reason, wear rubber gloves if necessary.

Floor Mate



4. Technical Data

pH level: 2.5 (concentrate)

Data on ingredients (EC recommendation): Less than 5% anionic surfactants, oxygen-based bleach. Contains aromas, LIMONENE, solvents, acids, stabilisers.

Giscode: n.d. (Product Code for Cleaning and Care Products)

Floor Mate should be stored in a cool, dry place in its closed original container. Protect from frost. Keep locked up and out of the reach of children.

5. Unit Sizes

6 x 400 ml bottle with atomiser

Art.-No. 1540040001

www.dr-schutz.com

The above advice on procedure for use is based on the best of our knowledge and the latest information available on cleaning technology. For this reason, when using our quality products, no damage will be incurred to the materials to be cleaned if strict attention is paid to the instructions printed on the container and the procedure suggested by us is followed. The use to which our products are put is, however, beyond our control. It is the responsibility of the user and does not release the user from making his own checks of the products supplied by us as to their suitability for the intended procedure and purposes. The information supplied by us is therefore non-binding and cannot be used as a basis for establishing the company's liability for any damage incurred. This also includes the infringement of any rights for the protection of third parties.

