

## CC-Dr. Schutz GmbH

Steinbrinksweg 30  
D-31840  
Hessisch Oldendorf  
Fax: +49-(0)5152-9779-30  
Tel: +49-(0) 5152-9779-0  
info@dr-schutz.com  
www.dr-schutz.com

Dr. Schutz UK Ltd.  
Unit 24, Anglo Business Park  
Smeaton close Aylesbury Bucks HP19 8UP  
Great Britain  
Fax: 01296-334 219  
Tel: 01296-437 827  
steve@dr-schutz.com  
www.dr-schutz.com

## Product-Information

# Laminate Cleaner

### 1. Product Description

Mild neutral cleaning agent for the initial and regular cleaning of laminate floors. Removes dirt, fat, grease and shoe marks. Does not leave a residue. For EN 13329-defined laminate floor coverings and laminate surfaces (including kitchen and bathroom furniture). Specifically developed for all click laminate floors.

### 2. Areas of Application

All kinds of laminated floors and surfaces (e.g. furniture in kitchen and bathroom).

### 3. Method of Application

Dilute Laminate Cleaner in a ratio of 1:200 (50 ml to 10 l of water) and lightly damp wipe over the floor with this solution. For larger surface areas use a dilution up 1:200 to 1:400 using the spray-cleaning method in combination with a monodisc machine such as the SRP 1 plus a white or red pad. Glue residues and stubborn stains can be removed with Elatex Universal Stain Remover.

**Consumption:** 1 l = 1000 m<sup>2</sup>

**Note:** Laminated floors or surfaces should never be damp or wet for a longer period of time. Especially the edges could swell up and change shape. Therefore always wipe with thoroughly wrung-out cloths and ensure that no "pools" are created on the floor.

### 4. Technical Data

pH level: approx. 7.5  
Product code for cleaning and care products (Giscode): GU 50

Data on ingredients (EC recommendation): less than 5% anionic surfactants, non-ionic surfactants. Contains BENZISTHIAZOLINONE, METHYLISOTHIALZOLINONE, perfume, CITRAL, LIMONENE, LINALOOL, solvents.

Laminate Cleaner should be stored in a cool, dry place in its closed original container. Protect from frost. Keep locked up and out of the reach of children.

# Laminate Cleaner

## 5. Certificate of Quality

Certified in Germany by the Forschungs- und Prüfinstitut für Facility Management GmbH, Metzingen (FIGR)

## 6. Unit Sizes

15 x 750 ml  
5 l canister

Art.-No. 2210075016  
Art.-No. 2210000501

[www.dr-schutz.com](http://www.dr-schutz.com)

*The above advice on procedure for use is based on the best of our knowledge and the latest information available on cleaning technology. For this reason, when using our quality products, no damage will be incurred to the materials to be cleaned if strict attention is paid to the instructions printed on the container and the procedure suggested by us is followed. The use to which our products are put is, however, beyond our control. It is the responsibility of the user and does not release the user from making his own checks of the products supplied by us as to their suitability for the intended procedure and purposes. The information supplied by us is therefore non-binding and cannot be used as a basis for establishing the company's liability for any damage incurred. This also includes the infringement of any rights for the protection of third parties.*