Handball Resin Remover

1. PRODUCT DESCRIPTION

Mixture of mild solvents. For cleaning stains, resins, shoe marks as well as for removing soiled wax films on parquet, wooden floors and other solvent-resistant surfaces. Particularly suitable for removing gripping resins on sports floors, where alkaline cleaner solutions can attack the substrates.

2. APPLICATION

For cleaning, place on the floor and mobilise contamination in sections by machine or manually with a nonscratching white pad. After a short soaking time, the dissolved dirt is removed with a dry cloth. Always use a fresh cloth so that the contamination is not only spread but also absorbed by the cloth. Depending on the degree of soiling and the thickness of the film to be removed, the process must be repeated.

Please note:

- Good ventilation recommended.

3. CONSUMPTION

As required.

4. DRYING TIME

The cleaned surface can be used again after evaporation. Evaporation can be accelerated by good ventilation.

- Low temperatures, increased air humidity and poor ventilation can significantly extend the drying time.

5. STORAGE

Store in a cool dry place. Unlimited shelf life in unopened original container. Keep out of the reach of children.

6. TECHNICAL DATA

Ingredients: solvent mixture

GISCODE GH10 (wood and stone care products, de-aromatized)(Germany)

ADR/RID: Not a dangerous good as defined by transport regulations.

CLP/GHS: GHS08, Danger Contains: Hydrocarbons, C10-C13, n-alkanes, isoalkanes, cyclics, < 2% aromatics. May be fatal if swallowed and enters airways Harmful to aquatic life with long lasting effects. . IF SWALLOWED: Immediately call a POISON CENTER/doctor/... Do NOT induce vomiting. Store locked up. Dispose of contents/container according to local/regional/national/international regulation. Repeated exposure may cause skin dryness or cracking. UFI: JDX0-80TT-9008-2ND6

Further information on labelling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.



Handball Resin Remover

7. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of eukula finishes.
- Safety Data Sheet available on request.
 www.dr-schutz.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.



Handball Resin Remover

Dr. Schutz - We Care About Floors

Headquarter (international) Germany	Dr. Schutz GmbH Holbeinstraße 17 53175 Bonn Germany	phone +49 (228) 95352-40 fax +49 (228) 95352-46 email: export@dr-schutz.com www.dr-schutz.com
United Kingdom	Dr. Schutz UK Ltd. Unit 24, Anglo Business Park, Smeaton Close, Aylesbury Bucks HP19 8UP United Kingdom	contact: Richard Nelson phone +44 (1296) 437827 fax +44 (1296) 334219 email: richard@drschutz.co.uk
Ireland	Dr. Schutz Ireland 35 Pic Du Jer Park, Ballinlough, Cork T12 R9F9 Republic of Ireland	contact: Paul O'Reardon mobile +353 87 767 8388 email: paul@drschutzireland.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.