

### **1. PRODUCT DESCRIPTION**

Alcohol-based wood floor primer. Roller primer for wood and cork floors. Can be used almost universally on all types of wood and cork floors. Can be used under all eukula lacquers and eukula hardwax oil +.

Barrier primer for eukula hardwax oil+ in the presence of drying retarding wood ingredients (for example some tropical woods). (\*)

- Emphasises the wood grain, warm colour appearance.
- Fast drying.
- Reduces the bonding of planks.
- Mild odour when working with the product.

### 2. APPLICATION

Recommendation: Wet wipe the entire substrate before application. Allow to dry back. Apply evenly and generously with a eukula roller at a minimum temperature of 15 °C

Please note:

- The professionally grouted and sanded sub-surface must be in a clean, dry condition, free of oil, wax and dust.
- Pre-watering the wood before applying solvent-based products in the raw wood application is recommended and improves adhesion, resistance and colour retention, especially under waterborne varnishes. (\*\*)
- Insufficiently saturated application can lead to roller marks on the floor.
- The temperature of the floor and material must not fall below +15°C during application and drying time. Ideal conditions are in the range of 18-25 °C.
- The technical rules are to be observed.

#### 3. CONSUMPTION

100-120 ml/m² (8-10 m²/l). More product might be needed on rough or absorbent surfaces.

#### 4. DRYING TIME

Can be further processed after approx. 60 minutes.

Low temperatures, increased air humidity and poor ventilation can significantly extend the drying time.



### 5. STORAGE

Store in a cool dry place. Shelf life in unopened original containers from date of manufacture: 24 months. Note the imprinted date of manufacture. Keep out of the reach of children.

#### 6. TECHNICAL DATA

Ingredients: Alcohols / synthetic resin Decopaint 2004/42/IIA(h)(750)750 / GISCODE G2 (Germany) ADR/RID: UN 1263, 3/III

CLP/GHS: GHS02, GHS07, Danger Highly flammable liquid and vapour. Causes serious eye irritation. Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. Use explosion-proof [electrical/ventilating/lighting/...] equipment. Wear protective gloves/protective clothing/eye protection/face protection. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower]. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Dispose of contents/container according to local/regional/international regulation. UFI: NKT0-00FA-T00G-YMRC

Further information on labeling and on safe handling can be found in the current Safety Data Sheet.

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied containers can be disposed of with household waste or with the collection of recyclables.

### 7. SPECIAL NOTES

- Please pay attention to the printed batch number. Only use products with the same batch number in one layer. In the case of different batches, mix these in a separate container before using.
- All indications based on 23°C/50% rH/ 3-fold change of air per hour. Existing conditions can vary and account for different results. Reference wood: oak.
- Conditionally recommended in areas where the occurrence of highly solvent-containing surface loads is to be expected (e.g. alcoholic hand disinfectants). Pre-testing regarding the load capacity of the lacquer structure is recommended.
- In case of high humidity, whitish drying due to condensing water is possible. Under improved conditions, roll on again.



### 8. CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of eukula finishes.
- Safety data sheet available on request.
- (\*) Please refer to Technical Information 110 "Surface treatment of exotic wood species".
- (\*\*) Please refer to Technical Information 103 "Why water before oiling?
  www.eukula.com / The quoted printed matter, as well as this Product Information in its updated form, is available on our homepage or on request from the address quoted below.



#### eukula – contact us

Headquarter (international) Germany

North America & Canada USA Dr. Schutz GmbH Holbeinstraße 17 53175 Bonn Germany

Schutz NA LLC 8701 Torresdale Ave, Suite P Philadelphia PA 19137 North America & Canada tel +49 (228) 95352-40 fax +49 (228) 95352-46 email: export@dr-schutz.com www.dr-schutz.com

contact: Sam Jamison tel +1 877 272 4889 mobile +1 610 310 2412 email: sam@dr-schutz.us