



eukula[®]
WOOD.FLOOR.LOVE

INTENSIVE CLEANER

1. PRODUCT DESCRIPTION

Gentle special deep cleaner. For dirty and weathered stone, wood, and WPC surfaces outdoors. For terraces, but also for furniture and walls. Works thoroughly, powerfully, and gently against dirt.

2. APPLICATION

Remove coarse dirt by sweeping or vacuuming. Mask off adjacent areas and protect them from getting wet.

Pre-wet the surface. Dilute the cleaner with water in a ratio of 1:3 to 1:5; use undiluted for stubborn dirt. Spread the cleaning solution on the pre-wet surface and leave to work for approx. 10 minutes. Treat the surface with a suitable scrubbing brush. Remove the dirty water. Rinse with clean water until completely removed.

After thorough cleaning, the floor must be reconditioned.

Notes:

- Do not allow the cleaning solution to dry on the floor during the cleaning process; therefore, work section by section.
- Before use, test the substrate for color and material compatibility in an inconspicuous area.
- We recommend using the Multiclean 350 machine with a hard scrubbing brush.

3. CONSUMPTION

100 ml/m² (10 m²/l).

4. STORAGE

Store in a cool, dry place. Keep out of reach of children.

5. TECHNICAL DATA

Ingredients: Water / less than 5% non-ionic surfactants, anionic surfactants / fragrances LIMONENE / alcohols

GISCODE GG20 (basic cleaner, not labeled, contains solvents).

ADR/RID: Not classified as dangerous goods according to transport regulations.

CLP/GHS: Not subject to labeling requirements. For further information on labeling and safe handling, please refer to the safety data sheet.

INTENSIVE CLEANER

Observe the usual precautions even when using low-pollutant products. Keep away from children. Empty containers can be disposed of with household waste or in the recycling collection.

6. CROSS-REFERENCES

Our following publications in their current form are considered part of this data sheet:

- General information on the use of Dr. Schutz surface products.
- Safety data sheet available on request.

www.dr-schutz.com / The printed materials listed, as well as this product information in its current form, are available on the homepage or on request from the address below.

eukula – contact us

Headquarters
Germany

Dr. Schutz GmbH
Holbeinstraße 17
53175 Bonn
Germany

tel
fax
email: zentrale@dr-schutz.com
www.dr-schutz.com

Switzerland

Reinwall GmbH
9500 Wil, Switzerland
Factory representative for Switzerland and
Liechtenstein:
Floor Concept GmbH

tel +41 (44) 5334500
fax +41 (44) 5334501
email: info@floorconcept.ch
www.floorconcept.ch

Austria

Contact: Michael Neubauer

tel +43 (664) 3562985
Fax +43 (463) 265526-8178
email: mne@dr-schutz.com

Our above application advice is based on our best knowledge and the latest state of the art. Therefore, if our products are used in accordance with the specified application instructions and the procedure we recommend for the materials for which these products are intended, no damage will occur. However, the use of our products is beyond our control, is your own responsibility, and does not exempt you from testing the products we supply for their suitability for the intended processes and purposes. Our advice is therefore non-binding and cannot be used as a basis for liability claims against us, including with regard to any third-party property rights. The relevant recommendations, guidelines, and standards, as well as the recognized rules of technology, must be observed.