Version: 23.05.2017

Super Stain Remover R





1 PRODUCT DESCRIPTION

Stain removal spray for the professional removal of especially stubborn water insoluble stains. Removes thoroughly and quickly glue and paint residues, edding pen, nail varnish etc.

2 AREAS OF APPLICATION

Colour resistant textile floor coverings, upholstery and textiles.

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

3 METHOD OF APPLICATION

Spray sparingly directly onto stains on carpets and textile floor coverings, dab carefully with absorbent cloth. For upholstery and textiles spray onto absorbent cloth and dab. Spray onto stains of chewing gum and dispersion paint, leave to draw for approx. 30 seconds, then dab carefully. Lift coarse residues for instance with a teaspoon or back edge of a knife. Then spray again and dab carefully.

Note: First test Super Stain Remover R on an inconspicuous area for colour fastness and material stability.

4 CONSUMPTION

As required.

5 STORAGE

Super Stain Remover R should be stored in a cool, dry place in its closed original container. Keep locked up and out of the reach of children.

6 TECHNICAL DATA

Ingredients: Contains perfumes, CITRAL, LIMONENE, solvents, propellants, n-butyl acetate 1-methoxy-2-propanol ethyl acetate

ADR/RID: UN1950 AEROSOLS, flammable.

CLP: GHS02, GHS07. Danger. H222-H229 Extremely flammable aerosol. Pressurised container: May burst if heated. H319 Causes serious eye irritation.. H336 May cause drowsiness or dizziness. H412 Harmful to aquatic life with long lasting effects.

P101 If medical advice is needed, have product container or label at hand. P102 Keep out of reach of children. P210 Keep away from heat, hot surfaces, sparks, open flames and other ignition sources. No smoking. P251 Do not pierce or burn, even after use. P211 Do not spray on an open flame or other ignition source.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P410+P412 Protect from sunlight. Do not expose to temperatures exceeding 50 °C/122 °F. P501 Dispose of contents/container in accordance with local/regional/national/international

Version: 23.05.2017





Super Stain Remover R

regulations.

EUH066 Repeated exposure may cause skin dryness or cracking. EUH208 Contains D-Limonen. May produce an allergic reaction.

Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under www.dr-schutz.com

8 CROSS REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.

Dr. Schutz - We Care About Floors

Headquarter
Dr. Schutz GmbH
Holbeinstraße 17
D-53175 Bonn
Tel.: +49 (0)228 / 95 35 2-40
Fax: +49 (0)228 / 95 35 2-46

Fax: +49 (0)228 / 95 35 2-46

E-Mail: export@dr-schutz.com

www.dr-schutz.com

Tel.: +44 (0)1296 437827

Fax: +44 (0)1296 334219

E-Mail: richard@dr-schutz.com

Ireland Dr. Schutz Ireland 35 Pic Du Jer Park, Ballinlough, Cork

> Contact: Paul O'Reardon Mobile: 0877678388 E-Mail: drschutzireland@gmail.com

North America Schutz NA 4701 Bath St 46 Philadelphia, PA 19137

Contact: Sam Jamison Tel.: +1(877) 272- 4889 Mobile: +1(215) 510- 7874 E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.

Dr. Schutz U.K Ltd.

HP19 8UP

Unit 24, Anglo Business Park,

Smeaton Close, Aylesbury Bucks